

Embroidered Patches

INSTRUCTIONS:



- PLACE PATCH ONTO GARMENT.



- TURN GARMENT OVER SO PATCH IS FACING DOWNWARDS. IRON ON REVERSE SIDE OF GARMENT.



- HEAT IRON TO 150°C. PROCEED TO IRON FOR 20-25 SECONDS FOR PATCH TO ADHERE. **CAUTION:** DO NOT USE STEAM IRON



- PROCEDURE IS COMPLETE

THE TEMPERATURE & TIME OF IRONING SHOULD BE ADJUSTED DEPENDING ON THE MATERIAL THICKNESS.

IF THE MATERIAL IS THICKER, MORE TIME WILL BE NECESSARY.

CAUTION: DO NOT EXCEED 35 SECONDS.

NOT SUITABLE ON THE FOLLOWING FABRICS:

- ACRYLIC MATERIAL
- WATER-PROOF MATERIAL
- FABRIC PROCESSED WITH SILICON

www.e-patchesandcrests.com